



Una posa a regola d'arte esige la perfetta planarità tra le piastrelle.

Spesso a causa di supporti (caldane) non perfettamente livellati, piastrelle di basso spessore e quindi flessibili, o piastrelle di grande formato e quindi pesanti anche prestando la massima attenzione non si riescono a collocare in maniera ottimale.

Come risultato, piastrelle che in fase di posa apparivano perfettamente livellate, a presa avvenuta dell'adesivo presentano invece dislivelli che ne compromettono l'estetica.

Tutto ciò si può evitare grazie all'uso dei distanziatori livellanti, che, oltre a mantenere il perfetto livellamento tra le piastrelle, velocizzano la posa.

Con i distanziatori livellanti la posa è facile, veloce e le piastrelle restano perfettamente livellate.

Larghezza minima del giunto/fuga: 2 mm. Spessore piastrella: minimo 3 mm, max 12 mm.

Sia il posizionamento del distanziatore livellante che la rimozione è semplice e veloce.

COME SI USA:

Posizionamento del supporto:

1. Dopo avere steso l'adesivo inserire il supporto al di sotto della piastrella in corrispondenza dei 4 lati.
2. In funzione del formato della piastrella posizionare uno o più supporti per ogni lato della piastrella.
3. Posizionare la piastrella e batterla con martello in gomma.

Inserimento del cuneo:

1. Inserire il cuneo nella feritoia del supporto facendo attenzione a non superare il punto di rottura.
2. Per agevolare l'inserimento del cuneo si consiglia l'uso della pinza a trazione regolabile.

Eliminazione del supporto:

A maturazione dell'adesivo avvenuta, la parte sporgente del supporto si separa dalla base battendo, nella direzione della linea di fuga, con un martello in gomma o con il piede o con la pinza a trazione regolabile.



A correct setting requires the perfect levelling of the tiles.

Very often it is hard to properly set flexible and low thickness tiles as well as big sized and heavy tiles because of the uneven floor foundation.

As a result, tiles which seemed perfectly levelled while installing them, once the adhesive set, they show differences in level that compromise the aesthetics.

This can be avoided thanks to the levelling spacers which preserve the perfect levelling of the tiles and, also, they speed up the setting.

So, the levelling spacers make the setting easy, fast and the tiles are perfectly levelled.

Minimum required joint: 2 mm (3/32"). Tile thickness: minimum 3 mm (1/8"), maximum 12 mm (1/2").

Both the positioning and the removal of the levelling spacers are easy and quick.

HOW TO USE:

How to set the support:

1. After having spread the adhesive, insert the support underneath the tiles and along the 4 sides.
2. According with tiles size, set one or more supports on every side of the tile.
3. Set the tile and beat it with a rubber mallet.

How to insert the wedge:

1. Insert the wedge in the support slot paying attention not to pass the breakpoint.
2. To facilitate this operation, the use of the special traction-adjustable-pliers is recommended.

How to remove the support:

Once the adhesive is set, the protruding part of the support, has to be removed by separating it from the base. This can be done thanks to the traction-adjustable-pliers, with a rubber mallet or even with feet. Beat parallel to the joint.

